

Playback Quick User Guide

1. Press STOP on the EDSR 100 DVR.
2. Press and hold the VCR button on the multiplexer until the light below the button is flashing, then release the button.
3. Press SEARCH on the DVR.
4. Highlight the DATE/TIME and press the ENTER button on the DVR. Use the ARROW keys to navigate around in menus.
5. Use the ARROW keys to select the time and date you want to search and then hit the ENTER button
6. Now tap the VCR button on the multiplexer twice or until the light below the button is solid.
7. You should now be viewing playback. You can pull up any camera full screen by hitting the corresponding camera number on the multiplexer.
8. When done playing back, press the STOP button on the DVR. Then, press the REC button on the DVR. Finally, tap the VCR button on the multiplexer once or until the light below the button goes off.

TIP: Just make sure you are recording when you're done otherwise your next incident won't get recorded